

Application tips for Mg-Krete:

- ✓ Always pour the Activator “juice” in the mixing pail first
- ✓ The only way to extend the working time is to use the Retarder in the mix.
- ✓ The dryer the mix (smooth Peanut Butter) the easier it is to finish the surface.
- ✓ Fold-up a wet towel, place on the side to periodically clean-off your trowel
- ✓ Always add the Retarder into the juice (when needed), mix for 15 seconds
- ✓ 3” wide steel trowels are the best to use, either 6”, 8” or 12” long
- ✓ If you grind the concrete surface to open the pores, it’s best to pre-spray area with the Juice.
- ✓ Wetting down the area with the juice helps the bonding on ground surface prep.
- ✓ The faster you mix the MG-Krete and get it out of the pail, the less ammonia smell.
- ✓ Always replace control and expansion joints
- ✓ On deeper repairs, always saw cut through the MG-Krete when replacing control joints.
- ✓ Swivel mixers and paddle mixers with 5 gal pails
- ✓ Never use Retarder in cold temps
- ✓ Most large skim coats are done in ½ bag mixes.
- ✓ Always slam-down pail and drag it out leaving MG-Krete about 1” thick.
- ✓ When doing multiple mixes, slam down second pail mix, drag out MG-Krete and quickly tie in cold joint.

